

CUSTOM COLORS & Cabinets

DIY Installation Tips

- No room entries, appliance doors, or cabinet doors should interfere with opening of appliances.
- Facing cabinets need enough room between them to have both doors opened simultaneously.
- Place a filler between the cabinet and the wall to ensure space to fully open the cabinet door.
- Wall cabinets are typically hung 18" above the countertop.
- An island should have at least 36" of space on all four sides.
- Leave room between the sink and cooktop for food preparation when they are adjacent another.
- Be sure that inward opening windows are not affected by sinks placed below it.
- House the dishwasher close to the sink to make loading and unloading easier.
- A sink or oven placed next to a wall limits workspace and disrupts workflow.
- A range should never be placed at the end of a run because of safety.